

Narcotics Cabinet with Audio/Visual Alarm, Single Door/ Single Electronic Push-Button Lock #27AVD20E

Specifications



Construction:

- Heavy-duty 18 gauge steel

Features:

- Electronic push-button combination lock
- Factory set user and supervisor code
- Cabinet may be programmed in the field
- AAA batteries can be replaced while cabinet remains locked
- Cabinet has integrated Audio and Visual alarm to alert personnel when open
- Battery-powered using standard 9 volt - Battery in quick-change holder
- Does not need to be hard-wired to electrical power – Can be mounted anywhere
- Full length stainless steel staked door hinges prevent pin removal
- Internal adjustable and/or removable shelf (1)
- Predrilled holes in the back for mounting on a wall, cabinet or other solid surface (wall mounting hardware included)
- Cabinet is delivered ready to use
- Twelve year warranty against manufacturer defect
- One year warranty on electronic and lock components

Available in Beige:



Dimensions:

- 12" W x 8" D x 18" H (30 cm x 20 cm x 45 cm)
- Net weight: 19.5 pounds (8.9 kg)
- Shipping dims: 15-5/8" W x 11"D x 19-5/8" H (39.7 cm x 28 cm x 49.9 cm)
- Approx. shipping weight: 23 pounds (10.5 kg)

Alarm Feature:

- Audible alarm volume is 84 dB measured at 12" (30.5 cm)
- Flashing light and audible alarm are activated when the outer door is opened
- Both alarms run off easy to replace 9 volt battery (estimated battery life of 3 months based on average daily use)