



- Powder Coat Steel
- Mobile Body
- Full Height
- Tambour Door
- Key Lock

# MEDSTOR<sup>MAX</sup>

## MSPM83-R0TK-SPLITB

### TRIPLE COLUMN STORAGE CABINET

#### Features:

- Unmatched quality of construction — built to last using professional grade design and manufacturing for medical-grade applications
- Roll-up tambour door with key lock allows access to supplies during clinical hours
- Designed with an open double column on the left, split into a double column below and an open column above with side panels on each column
- Stacks flush with walls or other cabinets — we don't use easily misplaced removable handles or bulky exterior hardware
- Features a true 24" interior cabinet depth able to store boxes two feet deep
- Customize your cabinet with any combo of trays, baskets, shelves or accessories
- Interior side panels allow 47 insertion points within each full column creating a system of multiple organization possibilities
- Modular trays can be pulled out at an angle, and "clip-on" locking safety features help minimize the risk of falling trays
- Industry best 5" quiet rolling Tente® casters for superior mobility - one steering and one braking caster
- Cabinet is delivered fully assembled

Available with shelves, baskets and trays, sold separately



Shown in  
Hammer-tone Gray.  
Also available in  
more than 20 color  
options or  
Stainless Steel.

#### Assembled Cart Dimensions:

- 85.6" H x 60" W x 28" D  
(217.4 cm H x 152.4 cm W x 71.1 cm D)
- Cart net weight: 404 lbs (183.3 kg)
- Approximate shipping weight: 624 lbs (283 kg)
- Approximate shipping dims: 90" H x 70" W x 38" D  
(228.6 cm H x 177.8 cm W x 96.5 cm D)

**Warranty:** 12-Year Limited Manufacturer's Warranty,  
1-Year Limited Warranty on any bought-out parts

For mobile or fixed storage, our versatile medical storage solutions provide high density and secure storage for valuable medical supplies used in surgical procedures. These med carts are designed around the most innovative modular tray system on the market and feature your choice of door style for security and ease of access.



View similar products online at  
<https://www.harloff.com/product-category/medstor-max-medical-storage/>

Toll Free: (800) 433-4064 • [medicalsales@harloff.com](mailto:medicalsales@harloff.com)  
[www.harloff.com](http://www.harloff.com) • Ph: (719) 637-0300



Engineered &  
Manufactured  
in the U.S.